



STEP THREE:
 LOCATE TARP POLE ON
 TOP CORNER OF COAMING

STEP TWO:
 FIT UP DRIVE WITH ARM

STEP ONE:
 MOUNT PIVOT BRACKET WITH
 BALANCE ARM IN POSITION
 MOUNT CABLE ANCHOR IN POSITION
 (REFER REVERSE SIDE OF PAGE)

STEP FOUR:
 ADJUST THREAD SO
 CABLE HAS SLACK
 REMOVED

1050 *

60

247

* Shorten to increase arm return force
 Lengthen to decrease arm return force.

RAZOR ©	Designed by darryl	Checked by	Approved by - date	Material	Date 28/10/2009	Sheet 2 / 2
	Razor International Pty Ltd			Rollover Tarp		Edition 03
					Drawing Number Installation	